



Arm depth,
width, & pivot

Arm height

Seat depth



Arm depth, width, & pivot – Move arm pad to the desired position.

Arm height – Lift lever, adjust arms to the desired height and release lever.

Lumbar – Grasp the lever and slide to the desired position.

Recline resistance – Sit upright and push the lever backward for the full range of recline or pull forward for upright support.

Seat depth – Lift the lever and move the seat to the desired position.

Seat height – Lift the lever, sit down to lower the seat and remove the weight to raise.



Arm depth,
width, & pivot

Arm height

Seat height &
recline resistance

Lumbar



Knoll - Regeneration

ISCG Inc.