



Arm depth, width, & pivot

Arm height

Seat depth



Lumbar

Arm depth, width, & pivot

Arm height

Seat height

Back stop, forward tilt, & tilt tension



Arm depth, width, & pivot –Grasp the arm pad and slide forward or back for depth, side-to-side for width, and rotate the front toward or away for pivot.

Arm height – Pull up on the lever and slide the armrest up or down.

Back Stop – (Back lever) Recline to the desired stopping position and push down on the lever to activate. Pull up on the lever to release.

Forward tilt – (Front lever) To activate, push down on forward tilt lever, recline, and then lean forward. Pull up and recline to release.

Lumbar – Pull up on the handles to raise, push down to lower. Rotate the handles up to increase the support and down to decrease. Each handle can be rotated independently.

Seat depth – Pull out and up on the lever at a 45° and slide the seat front to back.

Seat height – Pull the lever up and lift the body out of the chair to raise the seat. To lower, remain seated and pull the lever up.

Tilt tension – (Knob) Turn the crank forward to tighten and backward to loosen.

Haworth - Zody

ISCG Inc.