



Arm depth & width



Tilt limiter

Forward tilt

Aeron comes in 3 sizes. The sample chair is a size 2.

Arm depth & width – Move the arm pad forward or backward for depth and sideways for width.

Arm height – While seated, lift lever on back of arms and grasp base of arm support and raise or lower.

Forward tilt – (outer knob) To position chair forward, lean back and rotate the knob forward. Lean back and rotate lever back all the way to return.

Lumbar –Using equal pressure on each side of the support, raise or lower it to the desired position.

PostureFit SL – While seated, turn knob forward to engage. Turn knob backward to disengage.

Seat height – To raise the seat, with weight off the chair, lift the lever up. To lower, lift the lever up while seated.

Tilt limiter – (inside knob) To limit range, rotate knob forward to limit recline. Rotate all the way back to release.

Tilt tension control –While seated, to increase, turn the knob forward. To decrease, turn the knob backward.



Arm height

Lumbar

PostureFit SL



Arm depth & width

Seat height

Tilt tension control

## Herman Miller - Aeron

ISCG Inc.