



Arm depth,
width, & pivot
Arm height



Seat depth



Arm depth, width, & pivot
Arm height

Seat height

Tilt

Lumbar



Arm depth, width, & pivot – Slide the arm pad to the desired position.

Arm height – Lift the lever on the arm and lift arm to disengage. Slide the arm to the desired position and release the lever to lock.

Lumbar – Grasp both sides of the lumbar support and slide it to the desired position.

Seat depth – Seated, lift lever and slide the seat to the desired position.

Seat height – Lift the lever, sit down to lower the seat or remove your weight to raise it.

Tilt– Sit fully upright, rotate the back lever until it clicks into one of three positions. (All the way back for the most movement, middle for less, and all the way forward for greater upright support.)

Knoll - Generation

ISCG Inc.