



Arm height

Seat depth

Arm width

Tilt tension



Arm height

Seat depth

Arm width

Arm height – To raise the arms, pull up on the lever and pull up or down.

Arm width – To adjust the width, push up on the tab below the arm and move the arm inward or outward.

Back lock – Move your back to the desired position then push in on the lever. Pull the lever out for free-floating.

Seat back – Grasp the back with both hands, sitting or standing, and raise or lower the back.

Seat height – To lower, while seated, lift the lever. To raise the height, remove your weight and lift the lever.

Tilt tension – To increase the tension of the tilt, turn the dial clockwise. To decrease, turn the dial counter-clockwise.




Arm height

Arm width

Seat height

Back lock



Back lock

KI - Impress

ISCG Inc.