



Arm depth,
width, & pivot

Arm height



Arm depth, width, & pivot – Grasp arm pad and move front and back to change depth, move in or back to change width, and push front to left or right to change pivot.

Arm height – Push button in while moving arms up or down.

Back control – Turn dial for one of three settings. Counterclockwise all the way for weight –activated, the middle for more resistance than provided by the body, and clockwise all the way for upright back lock.

Lumbar – Grab the tabs and slide the lumbar support up or down.

Seat depth – Pull handle up and slide seat forward or back.

Seat height – To lower, hold handle up while seated. To raise, hold handle up while keeping your weight off the chair.

Lumbar

Arm depth, width,
& pivot

Arm height

Seat depth

Seat height

Back control



Steelcase – Series 1

ISCG Inc.