



Arm depth,
width, & pivot

Arm height

Tilt limiter &
forward tilt

Seat depth



Arm depth, width, & pivot – Grasp arm pad, push forward or back.

Arm height – Raise tab to unlock. Raise or lower arm, lower tab to lock.

Forward tilt – (front lever) To engage, recline and lift lever down. To release, recline and flip lever up.

Lumbar – Rotate the levers to loosen and slide support up or down. To increase the depth, rotate levers downward. To decrease depth, rotate the levers upward.

Seat depth – Squeeze handle below seat and adjust seat edge up or down. Release to lock.

Seat height – To raise, take weight off chair and lift tab up. To lower, lift tab up while seated.

Tilt limiter – (back lever) To engage, recline and move lever up to define the limit of the recline. To release, lean forward and press lever back.

Tilt tension – To increase, turn knob clockwise. To decrease, turn counterclockwise.

Lumbar



Arm depth,
width, & pivot

Arm height

Seat height

Tilt tension

Herman Miller - Mirra 2

ISCG Inc.